

It's too late once the concrete is placed

Even with a **3rd Party Processor** certificate to guarantee product quality, the safety and performance of the reinforced structure is compromised if the REO is not installed correctly.

Avoid these common mistakes when working with REO on site:

Avoid these common mistakes when working with REO on site.		
✗ Don't		√ Do
Bars bent out of position by plant	 X Hit or impact the bar with a sledge-hammer, tool, or plant X Use a piece of pipe to bend bars because it is not allowed in AS 3600 due to lack of control over site process 	✓ Use a hand-held power or manual bending tool that is fitted with a forming mandrel or pin to bend bars on site ✓ Get an SRIA processor member with the appropriate off-site equipment to bend bars > 20mm
Oxy acetylene removal of bars for service placement	 X Heat bars greater than 450°C because the yield strength reduces to 250 MPa X Remove structural reinforcement without Engineer's written permission X Cool steel bars by quenching with water 	 ✓ Undertake site welding with approved engineering procedure and qualified welder ✓ Allow normal air cooling of the bar after welding on site
Non-conforming bends to pre-galvanised reinforcing bar	X Bend bars around non- conforming pins using equipment, such as a brake press	✓ Bend bars around conforming pins on site using an approved bar bender ✓ Use an approved SRIA member with accurate processing equipment to bend bars
Lifting mesh for a driveway during concrete placement	X Lift steel reinforcement or tread into place during concrete placement	✓ Use approved AS/NZS 2425 bar chairs to support steel reinforcement during concrete placement

We all play a role in making Australia's building industry trustworthy, safe, and NCC compliant.

Ask for a 3rd Party Processor Certificate and check the REO installation.